VciMultiAhci

1) Functional Description

This component emulates a multi-channels disk controller respecting the AHCI standard. Each channel[k] can access a different physical disk, modeled as a file (one file per channel) belonging to the host system, and containing a complete disk image. Each channel[k] can perform data transfers between file[k] and a buffer in the physical memory of the virtual system. The number of supported channels, the file name(s), the VCI burst size, and the block size are hardware parameters, defined as constructor parameters. The number of channels cannot be larger than 8. The burst size must be a power of 2 between 8 and 64 bytes. The block size must be a power of 2 between 128 and 4096 bytes.

According to the AHCI specification, each channel[k] controller uses a private *Command List* that is handled as a software FIFO. For each channel[k], the *Command List* can register up to 32 *read* or *write* commands, that are handled in pseudo-parallelism by the channel controller. This VCI component has a DMA capability, and use it to access both the *Command List* and to transfer the data to or from memory.

On the VCI side, it supports both 32 bits and 64 bits data words, and up to 64 bits address width.

For each channel, a single IRQ[k] can be (optionally) asserted as soon as at list one command in the Command List is completed. WARNING: the IRQ[k] is associated to a specific channel, but not to a specific command.

This hardware component checks for segmentation violation, and can be used as a default target.

2) Command List

For each channel, the VciMultiAhci driver must use a software FIFO to register a command: The Command Descriptor array (32 entries) define the Command List. Each Command Descriptor occupies 16 bytes, and contains mainly the physical address of the associated Command Table. A command Descriptor is defined by the following C structure:

```
typedef struct hba_cmd_desc_s // size = 16 bytes
                   flag[2];
   unsigned char
                                    // WRITE when bit 6 of flag[0] is set
   unsigned char
                     prdt1[2];
                                     // Number of buffers
   unsigned int
unsigned int
                     prdbc;
                                     // Number of bytes actually transfered
                      ctba;
                                     // Command Table base address 32 LSB bits
   unsigned int
                      ctbau;
                                      // Command Table base address 32 MSB bits
} hba_cmd_desc_t;
```

3) Command Table

There is one Command Table for each Command descriptor. For a given command, there is one single LBA (Logic Bloc Address) on the block device, coded on 48 bits, but the source (or destination) memory buffer can be split in a variable number of contiguous buffers. Therefore, the Command Table contains two parts: a fixed size Header, defining the LBA, and an array of buffer descriptors containing up to 248 buffer descriptors. A Command Table occupies 4 Kbytes, and is defined by the following C structures:

```
typedef struct hba_cmd_table_s // size = 4 Kbytes
{
```

VciMultiAhci 1

```
// contains LBA
      hba_cmd_header_t header;
      hba_cmd_buffer_t buffer[248]; // 248 buffers max
} hba_cmd_table_t;
typedef struct hba_cmd_header_s // size = 128 bytes
                                    res0;
lba0;
     unsigned int res0; // reserved unsigned char lba0; // LBA 7:0 unsigned char lba1; // LBA 15:8 unsigned char lba2; // LBA 23:16 unsigned char res1; // reserved unsigned char lba3; // LBA 31:24 unsigned char lba4; // LBA 39:32 unsigned char lba5; // LBA 47:40 unsigned char res2; // reserved unsigned int res[29]; // reserved ba cmd header t:
                                                           // LBA 23:16
                                                          // LBA 31:24
                                                          // LBA 39:32
                                                          // LBA 47:40
} hba_cmd_header_t;
typedef struct hba_cmd_buffer_s // size = 16 bytes
      unsigned int dba;
unsigned int dbau;
unsigned int res0;
unsigned int dbc;
                                                           // Buffer base address 32 LSB bits
                                                           // Buffer base address 32 MSB bits
                                                          // reserved
                                                          // Buffer byte count
} hba_cmd_buffer_t;
```

4) Addressable registers

Each channel[k] contains six 32 bits read/write registers:

• HBA_PXCLB

32 LSB bits of the Command List physical base address. This address must be aligned on a 16 bytes boundary.

• HBA PXCLBU

32 MSB bits of the Command List array physical address.

• HBA_PXIS

Channel status, used for error reporting.

```
31 30 29 28 ... 24 23 ..... 8 7 ... 1 0 -- R -- CMD_ID BUFFER_ID ----- D
```

- Bit[0] : set by hardware when at least one command has been completed.
- Bit[30]: set by hardware when an error has been detected in a command.
- Bit[28:24]: index of the faulty command in command list.
- Bit[23:8]: index of the faulty buffer in the faulty command.

When an error is detected for a command, the R bit is set, the channel FSM stops immediately, without handling the remaining commands in the command list, and keep blocked, waiting for a software reset on this PXIS register.

• HBA_PXIE

3) Command Table 2

This register enables and disables the IRQ reporting the completion (success or error) of the commands for a given channel. Only 2 bits are used:

- Bit 0 : when set, an IRQ is generated when bit0 of AHCI_PXIS is set,
- Bit 30: when set, an IRQ is generated when bit 30 of AHCI_PXIS is set,
- HBA PXCMD

Boolean: The corresponding channel is activated to poll the command list when non zero.

• HBA_PXCI

Bit-vector, one bit per command in the Command List. These bits are handled as 32 set/reset flip-flops: set by software when a command ha been posted in Command List / reset by hardware when the command is completed.

For extensibility issues, you should access this component using these globally-defined offsets.

5) Component definition & usage

source:trunk/soclib/soclib/module/connectivity component/vci multi ahci/caba/metadata/vci multi ahci.sd?

6) CABA Implementation

CABA sources

- interface :
 - source:trunk/soclib/soclib/module/connectivity_component/vci_multi_ahci/caba/source/include/vci_multi_ahci.h?
- implementation :

source:trunk/soclib/soclib/module/connectivity_component/vci_multi_ahci/caba/source/src/vci_multi_ahci.cpp?

CABA Constructor parameters

CABA Ports

- p_resetn : Global system reset
- **p_clk** : Global system clock
- p_vci_target : The VCI target port
- p vci initiator : The VCI initiator port
- *p_channel_irq : Interrupt ports (one per channel)

7) TLM-DT Implementation

Not available yet.