Writing TLM2.0-compliant timed SystemC simulation models for SoCLib

Authors : Alain Greiner, François Pêcheux, Aline Vieira de Mello

- 1. A) Introduction
- 2. B) VCI initiator and VCI target
- 3. C) VCI Transaction in TLM-T
- 4. D) VCI initiator Modeling
 - 1. D.1) Member variables & methods
 - 2. D.2) Sending a VCI command packet
 - 3. D.3) Receiving a VCI response packet
 - 4. D.4) Initiator Constructor
 - 5. D.5) Local Time Representation & Synchronization
 - 6. D.6) VCI initiator example
- 5. E) VCI target modeling
 - 1. E.1) Member variables & methods
 - 2. E.2) Receiving a VCI command packet
 - 3. E.3) Sending a VCI response packet
 - 4. E.4) Target Constructor
 - 5. E.5) VCI target example
- 6. F) VCI Interconnect modeling
 - 1. F.1) Generic network modeling

A) Introduction

This document is still under development.

It describes the modeling rules for writing TLM-T SystemC simulation models for SoCLib that are compliant with the new TLM2.0 OSCI standard. These rules enforce the PDES (Parallel Discrete Event Simulation) principles. In the TLM-T approach, we don't use the SystemC global time, as each PDES process involved in the simulation has its own local time. PDES processes (implemented as SC_THREADS) synchronize through messages piggybacked with time information. This timing information is actually the absolute locat time of the sender. Models complying to these TLM-T rules can be used with the "standard" OSCI simulation engine (SystemC 2.x) and the TLM2.0 library, but can also be used also with others simulation engines, especially parallelized simulation engines.

The pessimistic PDES algorithm relies on temporal filtering of the incoming messages. A PDES process that has N input channels is only allowed to process when it has timing information on all its input ports. For example, an interconnect is only allowed to let a command packet reach a given target when all the initiators that can address this target have sent at least one timed message. To solve this issue the PDES algorithm uses *nul message*. A null message contains no data, but only a time information. Moreover, all processes can be in two modes: active & non-active. Only processes that are active participate to the temporal filtering.

A first implementation of TLMT used *sollicited null messages*, but the final solution uses *direct null-messages*, that strictly follow the Chandy-Misra pessimistic algorithm. Each process cannot run independently without sending a timed message for a time larger that a predefined value, called the SYNCHRONIZATION_TIME_QUANTUM. When this time quantum is elapsed, the process must send a null message on its output ports.

The models following the writing rules defined herein are syntactically compliant with the TLM2.0 standard, but have a different representation for the time. In particular, the third parameter of the transport functions is considered to be an absolute (but local) time and is not an offset relative to a global simulation time that is not used

A) Introduction 1

anymore. The examples presented below use the VCI/OCP communication protocol selected by the SoCLib project, but the TLM-T approach described here is very flexible, and is not limited to the VCI/OCP communication protocol.

The interested user should also look at the general SoCLib rules.

B) VCI initiator and VCI target

Figure 1 presents a minimal system containing one single VCI initiator, **my_initiator**, and one single VCI target, **my_target**. The initiator behavior is modeled by the SC_THREAD **execLoop**(), that contains an infinite loop. The interface function **nb_transport_bw**() is executed when a VCI response packet is received by the initiator module.

10

Unlike the initiator, the target module has a purely reactive behaviour and is therefore modeled as a simple interface function. In other words, there is no need to use a SC_THREAD for a target component: the target behaviour is entirely described by the interface function **nb_transport_fw**(), that is executed when a VCI command packet is received by the target module.

The VCI communication channel is a point-to-point bi-directional channel, encapsulating two separated uni-directional channels: one to transmit the VCI command packet in the **nb_transport_fw()** function, one to transmit the VCI response packet in the **nb_transport_bw()** function.

C) VCI Transaction in TLM-T

The TLM2.0 standard defines a generic payload that contains almost all the fields needed to implement the complete vci protocol. In SocLib, the missing fields are defined in what TLM2.0 calls a payload extension. The C++ class used to implement this extension is **soclib_payload_extension**.

The SocLib payload extension only contains four data members:

The m_soclib_command data member supersedes the command of the TLM2.0 generic payload. The parameter to the set_command() of a generic payload is always set to tlm::TLM_IGNORE_COMMAND. Seven values can be assigned to m_soclib_command. These values are:

```
VCI_READ_COMMAND,
VCI_WRITE_COMMAND,
VCI_LINKED_READ_COMMAND,
VCI_STORE_COND_COMMAND,
PDES_NULL_MESSAGE,
PDES_ACTIVE,
PDES_INACTIVE
```

The VCI_READ_COMMAND (resp. VCI_WRITE_COMMAND) is used to send a VCI read (resp. write) packet command. The VCI_LINKED_READ_COMMAND and VCI_STORE_CONDITIONAL_COMMAND are used to implement atomic operations. The latter 3 values are not directly related to VCI but rather to the PDES simulation algorithm. The PDES_NULL_MESSAGE value is used whenever an initiator needs to send its local time to the rest of the platform for synchronization purpose. The PDES_ACTIVE and PDES_INACTIVE values are used to inform the interconnect that the corresponding initiator must be taken into account in the temporal

filtering or not. For example, a programmable DMA controller should not participate in the PDES temporal filtering until it has been programmed and launched. At the beginning of the simulation, all the initiators send at least one synchronization message.

The data members of the **soclib_payload_extension** can be accessed through the following access functions:

```
// Command related methods
bool
           is read() const {return (m soclib command == VCI READ COMMAND);}
           set_read() {m_soclib_command = VCI_READ_COMMAND;}
void
bool
           is_write() const {return (m_soclib_command == VCI_WRITE_COMMAND);}
void
           set_write() {m_soclib_command = VCI_WRITE_COMMAND;}
bool
           is_locked_read() const {return (m_soclib_command == VCI_LINKED_READ_COMMAND);}
void
            set_locked_read() {m_soclib_command = VCI_LINKED_READ_COMMAND;}
            is_store_cond() const {return (m_soclib_command == VCI_STORE_COND_COMMAND);}
bool
            set_store_cond() {m_soclib_command = VCI_STORE_COND_COMMAND;}
bool
            is_null_message() const {return (m_soclib_command == PDES_NULL_MESSAGE);}
void
            set_null_message() {m_soclib_command = PDES_NULL_MESSAGE;}
            is_active() const {return (m_soclib_command == PDES_ACTIVE);}
bool
            set_active() {m_soclib_command = PDES_ACTIVE;}
void
           is_inactive() const {return (m_soclib_command == PDES_INACTIVE);}
bool
void
           set_inactive() {m_soclib_command = PDES_INACTIVE;}
enum command get_command() const {return m_soclib_command;}
       set_command(const enum command c) {m_soclib_command = c;}
// identification related methods
unsigned int get_src_id() const {return m_src_id;}
void set_src_id(unsigned int id) {m_src_id = id;}
unsigned int get_trd_id() const {return m_trd_id;}
void set_trd_id(unsigned int id) {m_trd_id = id;}
unsigned int get_pkt_id() const {return m_pkt_id;}
            set_pkt_id(unsigned int id) {m_pkt_id = id;}
```

To build a new VCI packet, one has to create a generic payload and a soclib payload extension, and to call the appropriate access functions on these two objects. For example, to issue a VCI read command, one should write the following code:

```
tlm::tlm_generic_payload *payload_ptr = new tlm::tlm_generic_payload();
soclib_payload_extension *extension_ptr = new soclib_payload_extension();
// set the values in tlm payload
payload_ptr->set_command(tlm::TLM_IGNORE_COMMAND);
payload_ptr->set_address(0x10000000]);
payload_ptr->set_byte_enable_ptr(byte_enable);
payload_ptr->set_byte_enable_length(nbytes);
payload_ptr->set_data_ptr(data);
payload_ptr->set_data_length(nbytes);
// set the values in payload extension
extension_ptr->set_read();
extension_ptr->set_src_id(m_srcid);
extension_ptr->set_trd_id(0);
extension_ptr->set_pkt_id(pktid);
// set the extension to tlm payload
payload_ptr->set_extension (extension_ptr);
```

D) VCI initiator Modeling

D.1) Member variables & methods

In the proposed example, the initiator module is modeled by the **my_initiator** class. This class inherits from the standard SystemC **sc_core::sc_module** class, that acts as the root class for all TLM-T modules.

The initiator uses the class **pdes_local_time** for managing and interacting with his local time and with the interval between two consecutive null messages. The **pdes_local_time** has the following access functions:

The initiator activity status (used by the temporal filtering, as described in section F) is managed for the class **pdes_activity_status**. The corresponding access functions are **set()** and **get()**.

The **execLoop()** method, describing the initiator behaviour must be declared as a member function.

The **my_initiator** class contains a member variable **p_vci_init**, of type **tlm_utils::simple_initiator_socket**, representing the VCI initiator port.

It must also define an interface function to handle the VCI response packets.

D.2) Sending a VCI command packet

To send a VCI command packet, the **execLoop()** method must use the **nb_transport_fw()** method, defined by TLM2.0, that is a member function of the **p_vci_init** port. The prototype of this method is the following:

The first argument is a pointer to the payload (including the soclib payload extension), the second represents the phase (always set to TLM::BEGIN_REQ for requests), and the third argument contains the initiator local time. The return value is not used in this TLM-T implementation.

The **nb_transport_fw**() function is non-blocking. To implement a blocking transaction (such as a cache line read, where the processor is stalled during the VCI transaction), the model designer must use the SystemC **sc_core::wait(x)** primitive (**x** being of type **sc_core::sc_event**): the **execLoop()** thread is then suspended, and will be reactivated when the response packet is actually received.

D.3) Receiving a VCI response packet

To receive a VCI response packet, an interface function must be defined as a member function of the class **my_initiator**. This function (named **nb_transport_bw**() in the example), must be linked to the **p_vci_init** port, and is executed each time a VCI response packet is received on the **p_vci_init** port. The function name is not

constrained, but the arguments must respect the following prototype:

The return value (type tlm::tlm_sync_enum) is not used in this TLM-T implementation, and must be sytematically set to tlm::TLM COMPLETED.

D.4) Initiator Constructor

The constructor of the class **my_initiator** must initialize all the member variables, including the **p_vci_init** port. The **nb_transport_bw()** function being executed in the context of the thread sending the response packet, a link between the **p_vci_init** port and this interface function must be established.

The constructor for the **p vci init** port must be called with the following arguments:

```
p_vci_init.register_nb_transport_bw(this, &my_initiator::nb_transport_bw);
```

D.5) Local Time Representation & Synchronization

The SystemC simulation engine behaves as a cooperative, non-preemptive multi-tasks system. Any thread in the system must stop execution at some point, in order to allow the other threads to execute. Moreover each PDES process must send null message periodically.

To solve this issue, it is necessary to define -for each initiator module- a **synchronization time quantum** parameter. This parameter defines the maximum delay between two successive timed messages. When this time quantum is elapsed, the component send a null message, and the corresponding thread is descheduled.

This time quantum mechanism is implemented in the **pdes_local_time** class. For each initiator, the time quantum value is a parameter defined as a constructor argument. The three members methods are...

D.6) VCI initiator example

```
#include "my_initiator.h"
                                         // header
my_initiator::my_initiator
( sc_core::sc_module_name name,
                                         // module name
 const soclib::common::IntTab &index,
                                        // index of mapping table
 const soclib::common::MappingTable &mt, // mapping table
 sc_core::sc_time time_quantum)
                                         // time quantum
 : sc_module(name),
                                         // init module name
   m_mt (mt),
                                         // mapping table
   p_vci_init("socket")
                                         // vci initiator socket name
 //register callback function VCI INITIATOR SOCKET
 p_vci_init.register_nb_transport_bw(this, &my_initiator::my_nb_transport_bw);
  //initiator identification
 m_srcid = mt.indexForId(index);
 //PDES local time
 m_pdes_local_time = new pdes_local_time(time_quantum);
 //PDES activity status
 m_pdes_activity_status = new pdes_activity_status(true);
 // register thread process
 SC_THREAD (execLoop);
```

```
// send to interconnect the initiator activity status
void my_initiator::sendActivity()
 tlm::tlm_generic_payload *payload_ptr = new tlm::tlm_generic_payload();
 soclib_payload_extension *extension_ptr = new soclib_payload_extension();
                            phase;
 tlm::tlm_phase
 sc_core::sc_time
                            time;
  // set the active or inactive command
 if(m_pdes_activity_status->get()) extension_ptr->set_active();
 else extension_ptr->set_inactive();
 // set the extension to tlm payload
 payload_ptr->set_extension (extension_ptr);
 //set the tlm phase
 phase = tlm::BEGIN_REQ;
 //set the local time to transaction time
 time = m_pdes_local_time->get();
 //send a message with command equals to PDES_ACTIVE or PDES_INACTIVE
 p_vci_initiator->nb_transport_fw(*payload_ptr, phase, time);
 //wait a response
 wait(m_rspEvent);
// send to interconnect a null message with the initiator local time
void my_initiator::sendNullMessage()
 tlm::tlm_generic_payload *payload_ptr = new tlm::tlm_generic_payload();
 soclib_payload_extension *extension_ptr = new soclib_payload_extension();
 tlm::tlm_phase
                           phase;
                            time;
 sc_core::sc_time
 // set the null message command
 extension_ptr->set_null_message();
  // set the extension to tlm payload
 payload_ptr->set_extension(extension_ptr);
  //set the tlm phase
 phase = tlm::BEGIN_REQ;
  //set the local time to transaction time
 time = m_pdes_local_time->get();
 //send a null message
 p_vci_initiator->nb_transport_fw(*payload_ptr, phase, time);
  //deschedule the initiator thread
 wait(sc_core::SC_ZERO_TIME);
// initiator thread
void my_initiator::execLoop(void)
 tlm::tlm_generic_payload *payload_ptr = new tlm::tlm_generic_payload();
 soclib_payload_extension *extension_ptr = new soclib_payload_extension();
 tlm::tlm_phase phase;
 sc core::sc time time;
 uint32_t nbytes = 4;
 unsigned char data[nbytes];
 unsigned char byte_enable[nbytes];
 while (true) {
    //fill the byte_enable and data
    for(unsigned int i=0; i<nbytes; i++) {</pre>
     byte_enable[i]=0xFF;
     data[i]=0xAA;
    // set the values in tlm payload
    payload_ptr->set_command(tlm::TLM_IGNORE_COMMAND);
```

```
payload_ptr->set_address(0x10000000);
   payload_ptr->set_byte_enable_ptr(byte_enable);
    payload_ptr->set_byte_enable_length(nbytes);
    payload_ptr->set_data_ptr(data);
    payload_ptr->set_data_length(nbytes);
    // set the values in payload extension
    extension_ptr->set_write();
    extension_ptr->set_src_id(m_srcid);
    extension_ptr->set_trd_id(0);
    extension_ptr->set_pkt_id(0);
    // set the extension to tlm payload
   payload_ptr->set_extension (extension_ptr );
    // set the tlm phase
   phase = tlm::BEGIN_REQ;
    // set the local time to transaction time
    time = m_pdes_local_time->get();
    // send the transaction and wait a response
    p_vci_initiator->nb_transport_fw(*payload_ptr, phase, time);
    wait(m_rspEvent);
    // increment the local time
    m_pdes_local_time->add(10 * UNIT_TIME);
    // if a synchronization is nexcessary then the initiator sends a null message
   if (m_pdes_local_time->need_sync()) {
      sendNullMessage();
  } // end while true
  //desactive the initiator and inform to interconnect
 m_pdes_activity_status->set(false);
 sendActivity();
// inbound nb_transport_bw (VCI INITIATOR SOCKET)
tlm::tlm_sync_enum my_initiator::my_nb_transport_bw
( tlm::tlm_base_protocol_types::tlm_payload_type &payload, // payload
 tlm::tlm_base_protocol_types::tlm_phase_type &phase, // phase
                                                           // time
  sc_core::sc_time
                                                 &time)
  // update the local time
 m_pdes_local_time->set(time);
 // wake up the initiator thread
 m_rspEvent.notify(sc_core::SC_ZERO_TIME);
 return tlm::TLM_COMPLETED;
```

E) VCI target modeling

In this example, the **my_target** component handles all VCI command types in the same way, and there is no error management.

E.1) Member variables & methods

The class **my_target** inherits from the class **sc_core::sc_module**. The class **my_target** contains a member variable **p_vci_target** of type **tlm_utils::simple_target_socket**, representing the VCI target port. It contains an interface function to handle the received VCI command packets, as described below.

E.2) Receiving a VCI command packet

To receive a VCI command packet, an interface function must be defined as a member function of the class **my_target**. This function (named **nb_transport_fw**() in the example), is executed each time a VCI command packet is received on the **p_vci_target** port. The function name is not constrained, but the arguments must respect the following prototype:

The return value (type tlm::tlm_sync_enum) is not used in this TLM-T implementation, and must be sytematically set to tlm::TLM_COMPLETED.

E.3) Sending a VCI response packet

To send a VCI response packet the call-back function uses the **nb_transport_bw**() and has the same arguments as the **nb_transport_fw**() function. Respecting the general TLM2.0 policy, the payload argument refers to the same **tlm_generic_payload** object for both the **nb_transport_fw**() and **nb_transport_bw**() functions, and the associated interface functions. Only two values are used for the **response_status** field in this TLM-T implementation:

- TLM OK RESPONSE
- TLM_GENERIC_ERROR_RESPONSE

For a reactive target, the response packet time is computed as the command packet time plus the target intrinsic latency.

E.4) Target Constructor

The constructor of the class **my_target** must initialize all the member variables, including the **p_vci_target** port. The **nb_transport_fw()** function being executed in the context of the thread sending the command packet, a link between the **p_vci_target** port and the call-back function must be established. The **my_target** constructor must be called with the following arguments:

```
p_vci_target.register_nb_transport_fw(this, &my_target::nb_transport_fw);
```

E.5) VCI target example

```
#include "my_target.h"
my_target::my_target
```

```
( sc_core::sc_module_name name,
 const soclib::common::IntTab &index,
 const soclib::common::MappingTable &mt)
  : sc_module(name),
   m_mt(mt),
   p_vci_target("socket")
  //register callback fuction
 p_vci_target.register_nb_transport_fw(this, &my_target::my_nb_transport_fw);
  //identification
 m_tgtid = m_mt.indexForId(index);
my_target::~my_target(){}
// Virtual Fuctions tlm::tlm_fw_transport_if (VCI TARGET SOCKET)
tlm::tlm_sync_enum my_target::my_nb_transport_fw
                                                     // non-blocking transport call through
( tlm::tlm_generic_payload &payload,
                                                     // generic payoad pointer
  tlm::tlm_phase
                                                     // transaction phase
                         &phase.
  sc_core::sc_time
                         &time)
                                                     // time it should take for transport
  soclib_payload_extension *extension_pointer;
 payload.get_extension(extension_pointer);
 //this target does not treat the null message
 if(extension_pointer->is_null_message()){
   return tlm::TLM_COMPLETED;
 uint32_t srcid = extension_pointer->get_src_id();
 uint32_t nwords = payload.get_data_length() / vci_param::nbytes;
 uint32_t address = payload.get_address();
 switch(extension_pointer->get_command()){
 case soclib::tlmt::VCI_READ_COMMAND:
 case soclib::tlmt::VCI_WRITE_COMMAND:
 case soclib::tlmt::VCI_LINKED_READ_COMMAND:
 case soclib::tlmt::VCI_STORE_COND_COMMAND:
   //set response status
   payload.set_response_status(tlm::TLM_OK_RESPONSE);
   //modify the phase
   phase = tlm::BEGIN_RESP;
   //increment the target processing time
   time = time + (nwords * UNIT_TIME);
   //send the response
   p_vci_target->nb_transport_bw(payload, phase, time);
   return tlm::TLM_COMPLETED;
   break;
 default:
   break;
 //send error message
 payload.set_response_status(tlm::TLM_COMMAND_ERROR_RESPONSE);
  //modify the phase
 phase = tlm::BEGIN_RESP;
  //increment the target processing time
 time = time + nwords * UNIT_TIME;
  //send the response
 p_vci_target->nb_transport_bw(payload, phase, time);
 return tlm::TLM_COMPLETED;
```

F) VCI Interconnect modeling

The VCI interconnect used for the TLM-T simulation is a generic interconnection network, named **VciVgmn**. The two main parameters are the number of initiators, and the number of targets. In TLM-T simulation, we don't want to reproduce the detailed, cycle-accurate, behavior of a particular interconnect. We only want to simulate the contention in the network, when several VCI intitiators try to reach the same VCI target.

In a physical network such as the multi-stage network described in Figure 2.a, conflicts can appear at any intermediate switch.

The **VciVgmn** network, described in Figure 2.b, is modeled as a cross-bar, and conflicts can only happen at the output ports. It is possible to specify a specific latency for each input/output couple. As in most physical interconnects, the general arbitration policy is round-robin.

10

}

F.1) Generic network modeling

According to PDES, a packet P emitted by an initiator reaches the correct target when it is safe to do so, i.e. when the interconnect is sure that no initiator will send a packet with a timestamp lesser than the timestamp of P. This temporal filtering operation can be factorized, when all the connected active initiators have sent at least one message to the interconnect. These messages are stored in a centralized data structure. This structure stores tree information: the packet, the timestamps and the current initiator activity. After elaboration of the simulator, the activity information for each initiator is set to true. A coprocessor initiator will send a message with **m_soclib_command** set to **TLMT_INACTIVE** at the beginning of the simulation. Therefore, when all slots of this centralized structure are filled with real or null messages with their associated timestamps, a temporal filtering iteration can occur.

The arbitration process must take into account the actual state of the VCI initiators: For example a DMA coprocessor that has not yet been activated will not send request and should not participate in the temporal filtering and arbitration process. As a general rule, each VCI initiator must define an **active** boolean flag, defining if it should participate to the arbitration. This **active** flag is always set to true for general purpose processors.

There are actually two fully independent networks for VCI command packets and VCI response packets.

The two networks are not symmetrical:

- There is one processing thread for each output port (i.e. one processing thread for each VCI target). Each processing thread is modeled by a SC_THREAD, and contains a dedicated message fifo and a local time. This time represents the target local time.
- For the response network, there are no conflicts, and therefore there is no thread (and no local time). The response network is implemented by simple function calls.

This scheme is illustrated in Figure 3 for a network with 2 initiators and three targets:

Ø

The command network handles the two following tasks:

• Temporal filtering and arbitration of the requests from the initiators.

This task is activated when all the connected initiators have sent at least one message to the interconnect. The task computes the list of the messages that can actually be sent to the targets according to PDES. The list contains all the messages which timestamp belongs to the time interval [T, T+ interconnect_delay], where T is the smallest timestamp of all the messages in the interconnect. Priority between initiators with the same local time is computed using a traditional round-robin algorithm. The temporal filtering and arbitration task is executed in the context of the initiator that sends a new (possibly null) message.

• Routing of a filtered request packet to the correct target. Each target runs under the control of a processing thread and

has a dedicated message fifo. The routing wakes up the processing thread of the corresponding target, that empties the message fifo filled by the temporal filtering. The behavioral function of the target is executed in the context of the processing thread.