

## UNDER DEVELOPMENT

# ARM7TDMI Processor Functional Description

This hardware component is a ARM7TDMI processor core. This is only an ISS, which should be wrapped with an IssWrapper.

The simulation model is actually an instruction set simulator with an ARM7TDMI pipeline.

Currently it only exists in bigendian form.

## IMPORTANT: steps to apply before using the ARM7TDMI

Before compiling any SoClib simulator using the ARM7TDMI you will need to download the UNISIM ([<http://www.unisim.org>]) library (well, just a piece of it, the `unisim_lib`).

To do so just download it using svn from [?https://unisim.org/svn/devel/unisim\\_lib](https://unisim.org/svn/devel/unisim_lib) with the following command:

- `svn import ?https://unisim.org/svn/devel/unisim\_lib`

You will have to enter a username and password. If you do not have access to the UNISIM development, you can simply use 'guest'/'guest' for username and password respectively. Once you have downloaded UNISIM you will need to create a link in `trunk/soclib/lib/arm7tdmi/include/iss/` and `trunk/soclib/lib/arm7tdmi/src/iss/` to `<your_path_to_unisim_lib>/unisim`.

If you wish you can download the full UNISIM library by downloading `unisim_tools` and `unisim_simulators`:

- `svn import ?https://unisim.org/svn/devel/unisim\_tools`
- `svn import ?https://unisim.org/svn/devel/unisim\_simulators`

Finally you will have to set your `soclib.conf` file to compile correctly the ARM7TDMI component. Here you have an example of configuration:

```
# -*- python -*-

def _platform():
    """
    Retrieves platform information and make it look-like systemc's
    lib-xxx thing.

    Working so far with:
    * linux
    * darwin
    """
    import sys
    pf = sys.platform
    # Strip numeric suffix from platform name
    while pf[-1] in "0123456789":
        pf = pf[:-1]

    remap_pf = {'darwin':'macosx'}
    if pf in remap_pf:
```

```

        pf = remap_pf[pf]
    return pf

config.systemc = Config(
    base = config.systemc,
    dir = "${SYSTEMC}",
    os = _platform(),
)

config.my_toolchain = Config(
    base = config.toolchain,
    cflags = ['-ggdb', '-DSOCLIB', '-D__STDC_CONSTANT_MACROS', '-Wall', '-Wno-pmf-conversion']
)

config.default = Config(
    base = config.build_env,
    systemc = config.systemc,
    toolchain = config.my_toolchain,
    repos = "/tmp/build/sc",
)

```

## Component definition

Available in source:trunk/soclib/soclib/lib/arm7tdmi/metadata/arm7tdmi.sd

## Usage

ARM7TDMI has no parameters.

```
Uses('iss_wrapper', iss_t = 'common:arm7tdmi')
```

## ARM7TDMI Processor ISS Implementation

The implementation is in

- source:trunk/soclib/lib/arm7tdmi/include/iss/arm7tdmi.h
- source:trunk/soclib/lib/arm7tdmi/src/iss/arm7tdmi.cpp

The previous files use the ARM7TDMI implementation provided in the UNISIM library.

## Template parameters

This component has no template parameters.

## Constructor parameters

```
ARM7TDMIIss(
    sc_module_name name,    // Instance Name
    int ident);            // processor id

```

## Visible registers

UNDER DEVELOPMENT

# Interrupts

## UNDER DEVELOPMENT

The handling and prioritization of the interrupts is deferred to software.

## Ports

None, it is to the wrapper to provide them.