

VciFdAccess

1) Functional Description

This VCI component is both a target and an initiator.

- It is addressed as a target to be configured for a transfer.
- It is acting as an initiator to do the transfer

There is only one access context handled at a time, but the file descriptor can be changed for each operation, and several file descriptors can be open at the same time. An IRQ is optionally asserted when transfer is finished.

This hardware component checks for segmentation violation, and can be used as a default target.

It contains the following memory-mapped registers:

- FD_ACCESS_FD File descriptor for the transfer
- FD_ACCESS_BUFFER Physical address of the buffer in SoC memory
- FD_ACCESS_SIZE Size of the transfer (number of bytes)
- FD_ACCESS_HOW Type of open() operation
- FD_ACCESS_WHENCE Type of offset when changing file pointer
- FD_ACCESS_OP Type of operation, writing here initiates the operation.
This register goes back to FD_ACCESS_NOOP when operation is finished.
- FD_ACCESS_RETVAL Return value
- FD_ACCESS_ERRNO Errno
- FD_ACCESS_IRQ_ENABLE Boolean enabling the IRQ line
- FD_ACCESS_MODE (aliases with WHENCE) Mode for open() with a O_CREAT

The following operations codes are defined:

- FD_ACCESS_NOOP Nothing
- FD_ACCESS_OPEN open()
path: FD_ACCESS_BUFFER
FD_ACCESS_SIZE must contain the length of path
returned fd is in FD_ACCESS_RETVAL
- FD_ACCESS_CLOSE close()
- FD_ACCESS_READ read()

- FD_ACCESS_WRITE write()

- FD_ACCESS_LSEEK lseek()

For extensibility issues, you should access this component using globally-defined offsets. You should include file `soolib/fd_access.h` from your software, it defines FD_ACCESS_FD, FD_ACCESS_BUFFER, ...

Sample code:

```
#include "soolib/fd_access.h"

static const void* fd_base = 0xc0000000;

int open( const char *path, const int how, const int mode )
{
    soclib_io_set(fd_base, FD_ACCESS_BUFFER, (uint32_t)path);
    soclib_io_set(fd_base, FD_ACCESS_SIZE, strlen(path));
    soclib_io_set(fd_base, FD_ACCESS_HOW, how);
    soclib_io_set(fd_base, FD_ACCESS_MODE, mode);
    soclib_io_set(fd_base, FD_ACCESS_OP, FD_ACCESS_OPEN);
    while (soclib_io_get(fd_base, FD_ACCESS_OP))
        ;
    errno = soclib_io_get(fd_base, FD_ACCESS_ERRNO);
    return soclib_io_get(fd_base, FD_ACCESS_RETVAL);
}

int close( const int fd )
{
    soclib_io_set(fd_base, FD_ACCESS_FD, fd);
    soclib_io_set(fd_base, FD_ACCESS_OP, FD_ACCESS_CLOSE);
    while (soclib_io_get(fd_base, FD_ACCESS_OP))
        ;
    errno = soclib_io_get(fd_base, FD_ACCESS_ERRNO);
    return soclib_io_get(fd_base, FD_ACCESS_RETVAL);
}

// Beware your caches could contain stale memory image after this call
int read( const int fd, const void *buffer, const size_t len )
{
    soclib_io_set(fd_base, FD_ACCESS_FD, fd);
    soclib_io_set(fd_base, FD_ACCESS_BUFFER, (uint32_t)buffer);
    soclib_io_set(fd_base, FD_ACCESS_SIZE, len);
    soclib_io_set(fd_base, FD_ACCESS_OP, FD_ACCESS_READ);
    while (soclib_io_get(fd_base, FD_ACCESS_OP))
        ;
    errno = soclib_io_get(fd_base, FD_ACCESS_ERRNO);
    return soclib_io_get(fd_base, FD_ACCESS_RETVAL);
}

int write( const int fd, const void *buffer, const size_t len )
{
    soclib_io_set(fd_base, FD_ACCESS_FD, fd);
    soclib_io_set(fd_base, FD_ACCESS_BUFFER, (uint32_t)buffer);
    soclib_io_set(fd_base, FD_ACCESS_SIZE, len);
    soclib_io_set(fd_base, FD_ACCESS_OP, FD_ACCESS_WRITE);
    while (soclib_io_get(fd_base, FD_ACCESS_OP))
        ;
    errno = soclib_io_get(fd_base, FD_ACCESS_ERRNO);
    return soclib_io_get(fd_base, FD_ACCESS_RETVAL);
}

int lseek( const int fd, const off_t offset, int whence )
{
    soclib_io_set(fd_base, FD_ACCESS_FD, fd);
```

```

soclib_io_set(fd_base, FD_ACCESS_SIZE, offset);
soclib_io_set(fd_base, FD_ACCESS_WHENCE, whence);
soclib_io_set(fd_base, FD_ACCESS_OP, FD_ACCESS_LSEEK);
while (soclib_io_get(fd_base, FD_ACCESS_OP))
{
    ;
errno = soclib_io_get(fd_base, FD_ACCESS_ERRNO);
return soclib_io_get(fd_base, FD_ACCESS_RETVAL);
}

```

(add -I/path/to/soclib/include to your compilation command-line)

2) Component definition & usage

[source:trunk/soclib/soclib/module/connectivity_component/vci_fd_access/caba/metadata/vci_fd_access.sd?](#)

See [SoclibCc/VciParameters](#)

Uses('vci_fd_access', **vci_parameters)

3) CABA Implementation

CABA sources

- interface :
[source:trunk/soclib/soclib/module/connectivity_component/vci_fd_access/caba/source/include/vci_fd_access.h?](#)
- implementation :
[source:trunk/soclib/soclib/module/connectivity_component/vci_fd_access/caba/source/src/vci_fd_access.cpp?](#)

CABA Constructor parameters

```

VciFdAccess(
    sc_module_name name, // Component Name
    const soclib::common::IntTab & index, // Target index
    const soclib::common::MappingTable &mt ) // MappingTable

```

CABA Ports

- sc_in<bool> **p_resetn** : Global system reset
- sc_in<bool> **p_clk** : Global system clock
- soclib::caba::VciTarget<vci_param> **p_vci_target** : The VCI target port
- soclib::caba::VciInitiator<vci_param> **p_vci_initiator** : The VCI initiator port
- sc_out<bool> **p_irq** : Interrupt port

4) TLM-T Implementation

The TLM-T implementation is not yet available.