### VciMultiDma

## 1) Functional Description

As the VciDma component, this component moves data from a source memory buffer to a destination memory buffer. It is both a target and an initiator.

- It is addressed as a target to be configured for a transfer.
- It is acting as an initiator to do the transfer.

The VciMultiDma component supports up to 16 simultaneous DMA transfers, corresponding to 16 independant DMA channels. As there is only one VCI initiator port, the general arbitration policy between the active channels is round-robin.

The number of channels and the max burst length are constructor parameters. The burst length parameter must be multiple of 4 bytes.

This component makes the assumption that the VCI RDATA & WDATA fiels have 32 bits. The source buffer base address, the destination buffer base address and the buffer length mus be multiple of 4 bytes. The buffer length is not constrained to be a multiple of the burst length.

Each channel has its own set of memory mapped registers, and for each channel a specific IRQ can be is optionally asserted when transfer is completed.

Each channel k has 5 memory-mapped registers :

• DMA\_SRC[k] (Read / Write)

It defines the physical address of the source buffer.

• **DMA\_DST[k]** (Read / Write)

It defines the physical address of the destination buffer.

• DMA\_LEN[k] (Read / Write)

It defines the length of transfer, in bytes. This register must be written after writing into registers DMA\_SRC & DMA\_DST, as the writing into the DMA\_LEN register starts the transfer. This register gets back to 0 when transfer is finished. This register can be used to test the DMA coprocessor status.

• DMA\_RESET[k] (Write-only)

Writing any value into this pseudo-register makes a clean re-initialisation of the DMA coprocessor: The on-going VCI transaction is completed before the coprocessor returns the IDLE state. This write access must be used by the software ISR to aknowledge the DMA IRQ.

• DMA\_IRQ\_DISABLED[k] (Read / Write)

A non zero value disables the IRQ line. The RESET value is zero.

VciMultiDma 1

The aligned segment size associated to this VCI target is 1 Kbytes, as only 10 address bits are decoded: the 6 MSB bits define the target register, and the next 4 bits define the channel index.

For extensibility issues, you should access the DMA using globally-defined offsets, and you should include file soclib/dma.h in your software, it defines DMA\_SRC, DMA\_DST, DMA\_LEN, DMA\_RESET, DMA\_IRQ\_DISABLED.

This hardware component checks for segmentation violation, and can be used as a default target.

## 2) Component definition & usage

source:trunk/soclib/soclib/module/infrastructure component/dma infrastructure/vci multi dma/caba/metadata/vci multi dm

See SoclibCc/VciParameters

```
Uses( 'vci_multi_dma' )
```

# 3) CABA Implementation

### **CABA** sources

- interface:
  - source:trunk/soclib/soclib/module/infrastructure component/dma infrastructure/vci multi dma/caba/source/include/
- implementation :
  - source:trunk/soclib/soclib/module/infrastructure component/dma infrastructure/vci multi dma/caba/source/src/vci

### **CABA Constructor parameters**

#### **CABA Ports**

• p\_resetn : Global system reset

• p\_clk : Global system clock

• p\_vci\_target : The VCI target port

• p vci initiator : The VCI initiator port

• p\_irq[k] : As many output IRQ ports as the number of channels

## 4) TLM-DT implementation

The TLM-DT implementation is not available yet.